

Self-Dumping Hopper Assembly Instructions.


The bolts required to assembly this product come in 3 uniquely marked bags. Each bolt hole is cut with 1 of these 3 unique shapes. Use these shapes as a simple guide to match the bolts to their correct location. The bolt head must always touch the face of the shaped cut-out. It takes 2 people about 1 hour to assemble. Ensure proper safety equipment is used.








Tools required for assembly:

- 1/4" Punch (For aligning holes.)
- Impact wrench with 1/2" socket (Bolt tightening.)
- 1/2" Wrench
- 2 x 9/16" Wrench
- Pliers










7.) Tighten the handle latch. Adjust it so that the hopper is held securely to the base after locking the hopper.



9.) To secure the guide pipe, insert the blue washer then insert the split pin at the end of the guide pipe. (Shown above.) After inserting pin tighten all other bolts previously left loose.