


UTILITY CART ASSEMBLY INSTRUCTIONS MODEL NO'S JH486 & JH487


- Place the bottom level flat on the ground or a sturdy surface
 - Line up the legs with the four (4) corners
 - Using a rubber mallet, tap the legs on to each corner




- 3 Place the top shelf on the second level of four legs, making sure to line up the front faces
 - Tap the top shelf down into place with the rubber mallet
 - NOTE: Do Not add the top handles yet



Flip the cart to stand right side up on top of the casters
Insert handles and tap into place with rubber mallet



- Place the middle shelf on the first four legs.
 Make sure the front faces are lined up (front face has a curved lip lower than the back)
 - Tap the middle shelf down with the rubber mallet
 - Add four more legs and use the rubber mallet to tap down



4 • Flip the cart upside down and screw in each of the four (4) caster wheels into the holes on the corners

• Tighten the center bolt with a wrench

